

# Distressing Options

## Standard Distressing Options

We can use any or all of the following techniques to give your doors a distressed, worn look. Please request a photo or sample for further information.

- Cracks (cracks chiseled into stiles rails and panels)
- Over-sanding (sharp edges and corners softened off in a worn manner)
- Wavy Edges (edges chiseled in random areas)
- Wormholes (small pin holes in groups)
- Battered (miscellaneous dents and nicks)

## Premium Distressing Options

Only available on certain species, ask for details.

- Rough Sawn (panels and frames lightly sanded after being run through rough tooth bandsaw)
- Wire Brush (wire brush texture applied to entire door, or frames only)
- Weathered (includes multiple distressing techniques and “weathered” staining)

